

















KOORDVOETEN - PIEDS POSE CORDONNET - FEET PIPING

 <p>Ref : P6069H 1/4 Piping foot Double 1/4" high</p> <p>077.006.073</p>	 <p>Ref : P6069H 1/8 Piping foot Double 1/8" high</p> <p>077.006.080</p>	 <p>Ref : P6069H 3/16 Piping foot Double 3/16" high</p> <p>077.006.079</p>
 <p>Ref : P6069L 1/4 Piping foot Double 1/4" low</p> <p>077.006.077</p>	 <p>Ref : P6069L 1/8 Piping foot Double 1/8" low</p> <p>077.006.075</p>	 <p>Ref : P6069L 3/16 Piping foot Double 3/16" low</p> <p>077.006.076</p>
 <p>Ref : P6069S 1/4 Piping foot Double 1/4" slant</p> <p>077.006.078</p>	 <p>Ref : P6069S 1/8 Piping foot Double 1/8" slant</p> <p>077.006.074</p>	 <p>Ref : P6069S 3/16 Piping foot Double 3/16" slant</p> <p>077.006.081</p>
 <p>Ref : P6069J 1/4 Piping foot Double 1/4" snap-on</p> <p>077.006.070</p>	 <p>Ref : P6069J 1/8 Piping foot Double 1/8" snap-on</p> <p>077.006.071</p>	 <p>Ref : P6069J 3/16 Piping foot Double 3/16" snap-on</p> <p>077.006.072</p>
 <p>Ref : 40986x6 1/2 Welting foot Low center 1/2 Low shank</p> <p>077.040.989</p>	 <p>Ref : 40986x6 1/4 Welting foot Low center 1/4 Low shank</p> <p>077.040.986</p>	 <p>Ref : 40986x6 1/8 Welting foot Low center 1/8 Low shank</p> <p>077.040.988</p>
 <p>Ref : 40986x6 3/16 Welting foot Low center 3/16 Low shank</p> <p>077.040.987</p>	 <p>Ref : 40986x6 3/8 Welting foot Low center 3/8 Low shank</p> <p>077.040.990</p>	

