

BOREN (DRILLBOOR) - AIGUILLES A PERFORER - DRILL NEEDLES

BULLMER

| Model Type | Maat Mesure mm. | Ø 1 mm. | Ø 1,25 mm. | Ø 1,50 mm. | Ø 2 mm. | Ø 2,50 mm. | Ø 3 mm. |
|------------|-----------------------|-------------|-------------|-------------|-------------|-------------|---------|
| | | | | | | | |
| B 335 VS | 160 | 072.370.300 | 072.370.302 | 072.370.305 | 072.370.310 | 072.370.315 | |
| B 336 VS | 200 | 072.370.320 | | 072.370.325 | 072.370.330 | 072.370.335 | |

EASTMAN / MAIMIN / WOLF / etc.

| Model Type | Maat Mesure mm. | Ø 1 mm. | Ø 1,25 mm. | Ø 1,50 mm. | Ø 2 mm. | Ø 2,50 mm. | Ø 3 mm. |
|------------|-----------------------|---------|------------|------------|-------------|------------|---------|
| | | | | | | | |
| | 8" = 190mm. | | | | 072.370.300 | | |

| | | | | | | | |
|-------|--|--|--|--|--|-------------|-------------|
| | | | | | | | |
| 7 1/2 | | | | | | 070.370.120 | 070.370.130 |

| | | | | | | | |
|-------|--|--|--|--|--|-------------|-------------|
| | | | | | | | |
| 7 1/2 | | | | | | 072.370.170 | 072.370.180 |

SUPRENA / ETWA

| Model Type | Maat Mesure mm. | Ø 1 mm. | Ø 1,20 mm. | Ø 1,50 mm. | Ø 2 mm. | Ø 2,50 mm. | Ø 3 mm. |
|----------------|-----------------------|-------------|-------------|-------------|-------------|-------------|---------|
| | | | | | | | |
| Suprena 1081 H | 220mm (HO210) | 072.354.200 | 072.354.199 | 072.354.201 | 072.354.202 | 072.354.203 | |
| Etwa PR17 | | | | | | | |

BOORGELEIDERS - GUIDES POUR AIGUILLES A PERFORER - DRILLSOCKETS FOR SUPRENA / ETWA

| | | | | | | | | |
|----------------|--|-------|-------------|-------------|-------------|-------------|-------------|-------------|
| Suprena 1081 H | | HO211 | 072.354.205 | 072.354.204 | 072.354.206 | 072.354.207 | 072.354.208 | 072.354.209 |
| Etwa PR17 | | | | | | | | |