

**BOREN (DRILLBOOR) - AIGUILLES A PERFORER - DRILL NEEDLES**

**BULLMER**

Model Type	Maat Mesure mm.	Ø 1 mm.	Ø 1,25 mm.	Ø 1,50 mm.	Ø 2 mm.	Ø 2,50 mm.	Ø 3 mm.
B 335 VS	160	072.370.300	072.370.302	072.370.305	072.370.310	072.370.315	
B 336 VS	200	072.370.320		072.370.325	072.370.330	072.370.335	

**EASTMAN / MAIMIN / WOLF / etc.**

Model Type	Maat Mesure mm.	Ø 1 mm.	Ø 1,25 mm.	Ø 1,50 mm.	Ø 2 mm.	Ø 2,50 mm.	Ø 3 mm.
	8" = 190mm.				072.370.300		

7 1/2						070.370.120	070.370.130

7 1/2						072.370.170	072.370.180

**SUPRENA / ETWA**

Model Type	Maat Mesure mm.	Ø 1 mm.	Ø 1,20 mm.	Ø 1,50 mm.	Ø 2 mm.	Ø 2,50 mm.	Ø 3 mm.

Suprena 1081 H	220mm (HO210)	072.354.200	072.354.199	072.354.201	072.354.202	072.354.203	
Etwa PR17							

**BOORGELEIDERS - GUIDES POUR AIGUILLES A PERFORER - DRILLSOCKETS FOR SUPRENA / ETWA**

Suprena 1081 H	 HO211	072.354.205	072.354.204	072.354.206	072.354.207	072.354.208	072.354.209
Etwa PR17							