







**PRINTPLATEN - CIRCUITS ELECTRIQUE - CONTROL PC BOARDS**

 <p><b>Ref : 0027057002</b>                  PC board                  Bernina 801-802-803-811                  -817-830  <b>077.002.705</b></p>		 <p><b>Ref : 284910 - 220V</b>                  PC board                  Singer MSP7 - MP4                  Auto shut off  <b>077.284.910</b></p>		 <p><b>Ref : 317278-001</b>                  PC board                  Singer 9124, 9224  <b>077.317.278</b></p>	
 <p><b>Ref : 979123-005</b>                  = 979120-005 (220V)                  PC board with on/off                  switch                  Singer 6233-6234-6235-                  4610-4613-4617-4623  <b>077.979.123</b></p>		 <p><b>Ref : 979586-201(203)</b>                  PC board                  Singer 220V  <b>077.979.586</b></p>			
 <p><b>Ref : 92-322461-91</b>                  PC board for foot control                  90-222050-43  <b>077.322.461</b></p>		<p><b>Ref : 0004307100</b>                  Bernina 1005, 1008  <b>077.430.710</b></p>	<p><b>Ref : 008582901</b>                  Singer 7360  <b>077.858.290</b></p>	<p><b>Ref : 008584901</b>                  (220V)                  Singer 3810, 3820,                  3825  <b>077.858.490</b></p>	<p><b>Ref : 4117168-46</b>                  Viking 180  <b>077.411.716</b></p>
<p><b>Ref : 4118713-45</b>                  Viking 980, 990  <b>077.411.871</b></p>	<p><b>Ref : 4120110-45</b>                  Viking 980, 990  <b>077.412.011</b></p>	<p><b>Ref : 4120216-45</b>                  Viking 980, 990  <b>077.412.021</b></p>	<p><b>Ref : 4121927-50</b>                  Viking 100, 600SR  <b>077.412.192</b></p>		
<p><b>Ref : 93-050450-91</b>                  Pfaff 1221/2  <b>077.050.450</b></p>		<p><b>Ref : X55970001</b>                  Brother (NP) PC7000  <b>077.559.700</b></p>	<p><b>Ref : X56296001</b>                  Brother PC7000,                  PC7500, PC8000 -                  Babylock  <b>077.562.960</b></p>	<p><b>Ref : X58259101</b>                  Sensor board                  Brother PE100,                  PC7500                  Babylock                  Bernina  <b>077.582.591</b></p>	<p><b>Ref : X58330001</b>                  Brother PC7500,                  PC8000                  Babylock  <b>077.583.300</b></p>
<p><b>Ref : X58668001</b>                  Brother (NP) PE100                  Babylock                  Bernina  <b>077.586.680</b></p>	<p><b>Ref : X58732001</b>                  Board sensor                  Brother PE100                  Babylock EM1X  <b>077.587.320</b></p>	<p><b>Ref : X58749005</b>                  Module LCD                  Brother PE100,                  PE200                  Babylock                  Bernina  <b>077.587.490</b></p>	<p><b>Ref : X59204001</b>                  Brother PC7000  <b>077.592.040</b></p>	<p><b>Ref : X59561101</b>                  Power supply                  Brother PE100                  Babylock EM1  <b>077.595.611</b></p>	<p><b>Ref : X59573002</b>                  Brother PE100                  Babylock EM1/Spec.  <b>077.595.730</b></p>
<p><b>Ref : X59795001</b>                  Brother PC7500,                  PC8000  <b>077.597.950</b></p>	<p><b>Ref : X80960101</b>                  Brother PE8200                  Babylock ESE  <b>077.809.601</b></p>	<p><b>Ref : X80987001</b>                  Brother PE200                  Babylock EM2  <b>077.809.870</b></p>	<p><b>Ref : XA0450101</b>                  Brother PE200                  Babylock EM2  <b>077.045.010</b></p>	<p><b>Ref : 29-924815-26</b>                  Pfaff 784/6/7  <b>077.924.815</b></p>	<p><b>Ref : 92-322265-91</b>                  Resistor 220                  Viking  <b>077.322.265</b></p>

