


















**NAALDKLEMMEN - PINCES AIGUILLE - NEEDLE CLAMPS SINGER**

 <p><b>Ref : 129853001</b>          Needle clamp          Brother VX, PS series          Singer 4001          Babylock, Simplicity 9000          Janome  <b>077.129.853</b></p>	 <p><b>Ref : 163123</b>          Needle clamp          Singer 300-400-500-600-          700-800-900-2000          (If out, use 543623)  <b>077.163.123</b></p>	 <p><b>Ref : 163822</b>          GIB needle clamp          Singer          (for 163123)  <b>077.163.822</b></p>
 <p><b>Ref : 168507</b>          Needle clamp          Singer 117, 2623          Simplicity  <b>077.168.507</b></p>	 <p><b>Ref : 2054</b>          Needle clamp          Singer 15-30/66/HA1          Brother, Necchi, Morse,          Nelco, Janome/New          Home, Riccar  <b>077.002.054</b></p>	 <p><b>Ref : 283059</b>          GIB needle clamp          Singer Quantum XL1,          CXL  <b>077.283.059</b></p>
 <p><b>Ref : 283060</b>          Needle clamp          Singer Quantum XL, CXL  <b>077.283.060</b></p>	 <p><b>Ref : 313552</b>          GIB needle clamp          Singer 4610-23,          6233/34/35  <b>077.313.552</b></p>	 <p><b>Ref : 313798</b>          Needle clamp          Singer 6233/34/35, 4610-          4613-4617-6267/8-9100  <b>077.313.798</b></p>
 <p><b>Ref : 319729</b>          Needle clamp          Singer 240, 250, 350, 360,          1800, 6105, 6106, 6136  <b>077.319.729</b></p>	 <p><b>Ref : 353631</b>          Needle clamp          (body with screw)          Singer 6210-17, 452/5/8  <b>077.353.631</b></p>	 <p><b>Ref : 388194</b>          Needle clamp          Singer XL-6000  <b>077.388.194</b></p>
 <p><b>Ref : 357430</b>  <b>(357429-001)</b>          Needle clamp          Singer with screw 5605,          5610, 5705, 5710, 5417  <b>077.357.430</b></p>	 <p><b>Ref : 376520</b>          Needle clamp          Singer 14U34, 44, 234,          286  <b>077.376.520</b></p>	 <p><b>Ref : 37943-803</b>          GIB needle bar          Singer 6201-6217  <b>077.037.943</b></p>
 <p><b>Ref : 385029</b>          Needle clamp          Singer Quantum LE  <b>077.385.029</b></p>	 <p><b>Ref : 386106</b>          Needle clamp          Singer Quantum XL100  <b>077.386.106</b></p>	 <p><b>Ref : 387017</b>          Needle clamp          Singer Quantum XL150,          XL1000  <b>077.387.017</b></p>
 <p><b>Ref : 387467</b>          Needle clamp          Singer XL5000-LE  <b>077.387.467</b></p>	 <p><b>Ref : 412744</b>          Needle clamp          Singer 14U64  <b>077.412.744</b></p>	 <p><b>Ref : 45285</b>          Needle clamp          Singer 15-88, 15-90, 201-          2, 221, 301, 293B, 1200-1  <b>077.045.285</b></p>
 <p><b>Ref : 541788</b>          Needle clamp          Singer 20U  <b>085.541.788</b></p>	 <p><b>Ref : 072270</b>          Needle clamp          Singer 14J334  <b>077.072.270</b></p>	<p><b>Ref : E10102</b>          Needle clamp          Singer 14T948DS  <b>077.010.102</b></p> <p><b>Ref : 550797</b>          Needle clamp          Singer 14U557  <b>077.550.797</b></p>
<p><b>Ref : HP32098-2</b>          Needle clamp          Singer 9910, 9920, 9940  <b>077.032.098</b></p>	<p><b>Ref : 543623</b> - Needle clamp          complete Singer 457-530-          830-327/8/9-337/8-413/6/8-          466-476/7/8  <b>077.543.623</b></p>	<p><b>Ref : 550398</b>          Needle clamp          Singer 14U555  <b>077.550.398</b></p>
<p><b>Ref : 550590</b>          Needle clamp          Singer 14U544, 14U554  <b>077.550.590</b></p>	<p><b>Ref : 74815</b>          Needle clamp          Singer 2638, 1500          (no screw)  <b>077.074.815</b></p>	<p><b>Ref : 80003</b>          Needle clamp          Singer 2662  <b>077.080.003</b></p>
<p><b>Ref : G10245000</b>          Needle clamp          Singer 1105/6, 1120/30  <b>077.102.450</b></p>	<p><b>Ref : H10205000</b>          Needle clamp          Singer 3810/20/25, 6510,          6550  <b>077.102.050</b></p>	<p><b>Ref : HP31961</b>          Needle clamp          Singer XL3400  <b>077.031.961</b></p>

**NAALDKLEMMEN - PINCES AIGUILLE - NEEDLE CLAMPS**  
**BABYLOCK-BERNINA-ELNA-JANOME/NEW HOME-PFAFF-RICCAR-NECCHI-VIKING/HUSQVARNA**

 <p><b>Ref : 125161100</b>          Needle clamp guide          Brother XL3010-3200          Babylock BL1556  <b>077.125.161</b></p>	 <p><b>Ref : SG-F12-00A</b>          Needle clamp          with needle bar          Babylock BL4-728/D  <b>077.010.042</b></p>	 <p><b>Ref : 0065197000</b>          Needle clamp          Bernina 1000-1630  <b>077.006.519</b></p>
 <p><b>Ref : 0068687100</b>          Needle clamp          Bernina 940, 950  <b>077.006.868</b></p>	 <p><b>Ref : 0082087001</b>          Needle clamp          Bernina with bar 120-170  <b>077.008.208</b></p>	 <p><b>Ref : 304.002.54</b>          Needle clamp          Bernina 830  <b>077.304.002</b></p>
<p><b>Ref : 304.247.14</b>          Needle clamp          Bernina 801-803,          940-950  <b>077.304.247</b></p>	<p><b>Ref : 095961-64</b>          Needle clamp          Elna green &amp; beige  <b>077.095.961</b></p>	 <p><b>Ref : 260502009</b>          Needle clamp          Elna 200-255          Viking          Simplicity  <b>077.260.502</b></p>
 <p><b>Ref : 395727-22</b>          Needle clamp          with needle bar          Elna with bar 6003/4  <b>077.395.727</b></p>	 <p><b>Ref : 411242-40</b>          Needle clamp          Elna Star, Air Electric  <b>077.411.242</b></p>	 <p><b>Ref : 462801-20</b>          Needle clamp          Elna 5000, 6000, Club,          Diva  <b>077.462.801</b></p>
 <p><b>Ref : 2054</b>          Needle clamp          Singer 15-30          Brother, Necchi, Morse,          Nelco, Janome/New          Home, Riccar  <b>077.002.054</b></p>	<p><b>Ref : 624185002</b>          Needle clamp          Janome Combi-10,          Combi-DX, 203, 303  <b>077.624.185</b></p>	<p><b>Ref : 785004020</b>          Needle clamp          Janome 234, 334  <b>077.785.004</b></p>
<p><b>Ref : 801506008</b>          Needle clamp          Janome 900-1500-SR2000-          RE3000-SD2014/15          Elna  <b>077.801.506</b></p>	<p><b>Ref : 822661007</b>          Needle clamp          Janome 5500, 6000  <b>077.822.661</b></p>	 <p><b>Ref : 129853001</b>          Needle clamp          Brother VX, PS series          Singer 4001          Babylock, Simplicity 9000          Janome  <b>077.129.853</b></p>
<p><b>Ref : SNZ3</b>          Needle clamp          Janome 370, 470          Babylock, Riccar,          Tacony, Brother,          Simplicity  <b>077.300.761</b></p>	<p><b>Ref : 93-034127-15</b>          Needle clamp          Body Pfaff 875-1171,          1213-7570  <b>077.034.127</b></p>	<p><b>Ref : 93-034128-05</b>          Needle clamp GIB          Pfaff most machines  <b>077.034.128</b></p>
<p><b>Ref : 93-034130-15</b>          Needle holder          Pfaff C-clip most models  <b>077.034.130</b></p>	 <p><b>Ref : 93-040784-91</b>          Needle clamp          Pfaff 1100-1200-230-260-          360  <b>077.040.784</b></p>	<p><b>Ref : 13068-T</b>          Needle clamp          Elna 300, 1500, 1600          Riccar  <b>077.013.068</b></p>
 <p><b>Ref : 4127738-01</b>          Needle clamp          Viking 100-900, #1  <b>077.412.773</b></p>	 <p><b>Ref : 4117503-02</b>          Needle clamp stopper for          4117503-01 Viking  <b>078.411.750</b></p>	 <p><b>Ref : 1643124-00</b>          Needle clamp          Necchi 533, 535  <b>077.164.312</b></p>
<p><b>Ref : 4110749-01</b>          Needle clamp          Viking most models  <b>077.411.074</b></p>	<p><b>Ref : SNZ11</b>          Needle clamp          Kenmore, Babylock,          Simplicity, Riccar  <b>077.300.763</b></p>	 <p><b>Ref : SNZ1</b>          Needle clamp          Jap. ZZ          Necchi  <b>077.300.760</b></p>

**NAALDKLEMMEN - PINCES AIGUILLE - NEEDLE CLAMPS BROTHER - WHITE**

 <p><b>Ref : 125161100</b>        Needle clamp guide        Brother XL3010-3200        Babylock BL1556  <b>077.125.161</b></p>	 <p><b>Ref : 2054</b>        Needle clamp        Singer 15-30        Brother, Necchi, Morse,        Nelco, Janome/New        Home, Riccar  <b>077.002.054</b></p>	
<p><b>Ref : SNZ3</b>        Needle clamp        Janome 370, 470        Babylock, Riccar,        Tacony, Brother,        Simplicity  <b>077.300.761</b></p>	<p><b>Ref : X53896001</b>        Needle clamp        Brother PS1900,        PC7500, PC8000        Babylock ESI, ES12  <b>077.053.896</b></p>	<p><b>Ref : X57282051</b>        Needle clamp        Brother        PS2200/2300/2500  <b>077.057.282</b></p>
<p><b>Ref : X75205-001</b>        Needle clamp        Brother 900D, 920D  <b>077.075.205</b></p>	<p><b>Ref : X75673-001</b>        Needle clamp        Brother 834DP  <b>077.075.673</b></p>	<p><b>Ref : X76511-001</b>        Needle clamp        Brother PL1600, 2000  <b>077.076.511</b></p>
<p><b>Ref : X76514-001</b>        Needle clamp        Brother PL1500  <b>077.076.514</b></p>	<p><b>Ref : X80880001</b>        Needle clamp        Brother PQ1300, PQ1500  <b>077.080.880</b></p>	<p><b>Ref : XA0643151</b>        Needle clamp        Brother VX1120, 1125,        1140  <b>077.006.431</b></p>
<p><b>Ref : XA1849101</b>        Needle bar &amp; needle        clamp        Brother PE8200        Babylock ESE  <b>077.001.849</b></p>	<p><b>Ref : XA5129251</b>        Needle clamp        Brother PE300S,        PE400D  <b>077.005.129</b></p>	<p><b>Ref : XA5718051</b>        Pin needle clamp        Brother XL5010-5300  <b>077.005.718</b></p>
<p><b>Ref : XA5779001</b>        Pin needle clamp        Brother PE300S,        PE400D  <b>077.005.779</b></p>	<p><b>Ref : XA6035001</b>        Pin needle clamp        Brother ULT2001        Babylock ES  <b>078.006.035</b></p>	<p><b>Ref : XB0302-001</b>        Needle clamp        Brother 929D  <b>077.000.302</b></p>
<p><b>Ref : XC2427051</b>        Needle clamp        Brother NX200/400/600  <b>077.002.427</b></p>	<p><b>Ref : XC3554051</b>        Needle clamp        Brother CS8100-CS8200  <b>077.003.554</b></p>	<p><b>Ref : XC4162021</b>        Needle block support        Brother CS810  <b>077.004.162</b></p>
<p><b>Ref : XZ0001051</b>        Needle clamp        Brother 5010/1, 5020/1,        5030  <b>077.000.105</b></p>	<p><b>Ref : XC2426020</b>        Needle clamp plate        Brother NV500D, SE270  <b>077.002.426</b></p>	<p><b>Ref : XC8560131</b>        Needle clamp        Brother CS100T,        CS4000, CS6000  <b>077.008.560</b></p>
 <p><b>Ref : 11713</b>        Needle clamp        White 228, 734D        (no screw)  <b>077.011.713</b></p>	 <p><b>Ref : 11934</b>        Needle clamp        White 7234, 7934  <b>077.011.934</b></p>	 <p><b>Ref : 12093</b>        Needle clamp        White S34/D, 299, 8234  <b>077.012.093</b></p>
 <p><b>Ref : 141000364</b>        Needle clamp        White 1500  <b>078.141.000</b></p>		